

Module *LCIIM* Lift Commission, Inspection, Installation and Maintenance

*Lift Commission, Inspection,
Installation and Maintenance*
LCIIM (14 h)



Aim: The aim of this module is: to enable the lift technician to: install, inspect the lift prior to commissioning and perform maintenance; to take correct measures to acquire assistance; and perform simple adjustments or replacement of parts in a WTG lift.

PROGRAM: LCIIM Lift Commission, Inspection, Installation and Maintenance

1. Introduction to the training
2. Legislation and documentation
 - 2.1 Lift manufacturer's manuals and guides
 - 2.2 Local and national legislation
3. Safety when working on a lift in a WTG
 - 3.1 Hazardous energy
 - 3.2 Work areas in the WTG
4. Gates and fences
 - 4.1 Outside the lift
 - 4.2 Gate lock systems
 - 4.3 Guard locking control system
 - 4.4 Upper and lower hatches
5. Cabin and its attachment parts
 - 5.1 The cabin - In general
 - 5.2 Fasteners and anchor points
 - 5.3 Service light and emergency light
6. Cabin guide unit
 - 6.1 Introduction to lift guiding systems
 - 6.2 Guide ropes
 - 6.3 Guide wheels
 - 6.4 Roller guide unit
 - 6.5 Guide ladder inspection
7. Top obstruction device
 - 7.1 Top obstruction device function
 - 7.2 Top obstruction flashing light
 - 7.3 Top obstruction in top position
8. Bottom obstruction device
 - 8.1 Bottom obstruction device function
 - 8.2 Bottom obstruction device - Bowden cable
 - 8.3 Bottom obstruction flashing light
 - 8.4 Bottom obstruction device stop in the lowest position
9. Lift door lock and electrical inter-lock
 - 9.1 Function test of the door lock
 - 9.2 Emergency unlocking
 - 9.3 Upper and lower hatches
10. Lift operation panel (LOP) and manoeuvre panel
 - 10.1 the lift operation and manoeuvre panel
 - 10.2 Operation hour counter
 - 10.3 Emergency rescue system
11. Suspension and crossbeam
 - 11.1 Suspension and crossbeam
 - 11.2 Rope end attachments
 - 11.3 bolts and bolts connections
 - 11.4 Upper and lower attack pinion (R&P)
12. Drive and safety wire rope and rack
 - 12.1 Drive ropes, in general
 - 12.2 Tension weights
 - 12.3 Grounding rotating unit
 - 12.4 Rope ends
 - 12.5 Counter rollers
 - 12.6 Rope clamps
 - 12.7 Rope attachments and bondings
 - 12.8 Rope protection
 - 12.9 Inspection of the rack
 - 12.10 Grease the rack
13. Traction hoist
 - 13.1 The traction hoist device
 - 13.2 Operation hour counter
 - 13.3 Labels and type plates on traction hoist
 - 13.4 Drive unit, mechanical
 - 13.5 Drive unit, electrical
 - 13.6 Upper and lower gearbox
 - 13.7 Electro-mechanical and centrifugal brakes

- 13.8 Load capacity system
14. Wire rope redirection inside the cabin
15. Fall arrest device (FAD)
 - 15.1 Labels and type plates
 - 15.2 General condition
16. Supply cable
 - 16.1 Feed-in of supply cable
 - 16.2 Strain relief
 - 16.3 Cable bin
17. Test and training review
 - 17.1 Theory test
 - 17.2 Training review
 - 17.3 Feedback session
 - 17.4 Participant performance assessment

LCIIM Module (Lift Commission, Inspection,
Installation and Maintenance)

Duration: 14 hours (2 days)
LCIIM Program : Sections 1 to 17
Maximum students: 12 people per Edition.

Certificate validity:

Permanent. No validity period applies to this training as long as the participant is active in the respective training.

Headquarter:

Cárcar (Navarra) • Spain

Phone: +34 948 674 881 • navarra@totalhse.com

Other centers in Spain:

Las Palmas (Canary Islands) • Spain

SEPROM

Phone: +34 902 008 482 • canarias@totalhse.com

Redondela (Galicia) • Spain

Verticalia Formación

Phone: +34 986 401 472 • galicia@totalhse.com

Other centers:

Hatzor Haglilit • Israel

IWTC

Phone: +972 4 632 2095 • israel@totalhse.com

San José • Costa Rica

Desarrollos Floruma

Phone: +506 2282-7468 • sanjose@totalhse.com

Santiago de Chile • Chile

ENACTRAR

Phone: +56 9 5819 5060 • chile@totalhse.com

www.totalhse.com

